

## FAQ Note

---

### No Analog Output

---

**Problem:** The instrument display reads correctly but there is no analog output signal.

**Explanation:** INCON indicates that an instrument is configured to produce an analog output signal, proportional to the displayed value, by a hyphen and a number immediately following the four-digit product model number. The number will be a “-0”, “-1”, “-2”, or “-4” to indicate what type of signal the instrument will output. If one of these numbers is not present in the model number, the instrument is not configured to output an analog signal.

The maximum allowable load resistance, through which the analog signal can be driven, for 0-1mA and +/-1mA analog outputs (“-0” and “-1”) is 10,000 ohms. The maximum allowable load resistance for 0-2mA analog output is 5,000 ohms. If this maximum load resistance is exceeded, the output signal will not function properly.

The instrument's analog output circuitry is protected from surges and unwanted voltages by the use of Transorb surge arrestors and small series resistors.


**Troubleshooting:**

1. Verify that the instrument is equipped with an analog output (as indicated above).
2. Create a short current loop: Remove all connections to the field load (RTU, Controller, PLC, etc...) Connect a milli-ammeter directly across the analog output terminals 1 & 2.
3. Using the analog output calibration mode (see the instrument's manual), force the analog output signal to its full scale HI output. Measure the output current at the instrument directly on terminals 1 & 2. If there is no output signal at all, proceed to the next step. If current can be measured but it is not the expected full scale current, skip to step #9. If no current is measured proceed to the next step.
4. Turn off power and remove the instrument from its case (squeeze the lock tabs on top and bottom of the front panel, pull firmly to slide the instrument out of the plastic case).
5. Check the gold PCB contact fingers inside the case. Look inside the case, at the bottom row of gold contacts. The analog output contacts are the two at the far right. Each contact has three slender fingers. If any of the fingers is bent up or seriously deformed, the instrument's PCB will not receive power through the case.
6. If a bent contact is found on an output terminal, remove the bent contact and replace it.
7. Check the resistance of the protection resistors R20 and R21 (see photo below). These resistors should measure less than 130 ohms. If either resistor measures greater than 130 ohms, replace the resistor with a new 120 ohm, 5%, 1/8 watt resistor.

# Application Bulletin

NO ANALOG OUTPUT FAQ NOTE.DOC

---



8. Reassemble the instrument. Repeat steps #2 & #3. If there is an output proceed to the next step. If the problem persists skip to step #10
9. Perform the analog output calibration procedure found in the instrument's manual. If the output cannot be properly calibrated there is an electronic failure, probably on the bottom PCB. Proceed to the next step. If the output can be properly calibrated skip to step #11.
10. There is probably an electronic component failure. Call the INCON Technical Support line (800-984-6266) for an RMA to return the instrument for repair.
11. Now that the output of the instrument is proven to be good, connect the output to the field load (RTU, Controller, PLC, etc...). If the output signal fails to work properly, the field load resistance is too high. There is trouble with the field load – not with the INCON instrument. Troubleshoot the field load.